

Notes regarding the Cine-tal File Structure on a USB key:

In order to access content from a USB Datakey from your Cinemage monitor, it is imperative that the Cine-tal File Structure be put in place, so that the monitor can follow the correct file paths to access the material.

To install the file system onto your USB Datakey:

1. download the zipped folder available at: <http://cine-tal.com/Download%20Library/Cine-tal%20File%20Structure.zip>, and save it to your computer.
2. Extract all the files (empty folders) to an easily accessible location.
3. Copy the File Folder "Cinetal" onto your USB Key (all the necessary folders are contained within the "Cinetal" folder).

Once these steps are complete, you will be able to load content into the folders to be accessed by the monitor. The below table illustrates where specific types of content should be placed within the Cine-tal file structure:

<i>File Type:</i>	<i>Location</i>
Software/ Firmware Updates	Cinetal Folder
3D LUTs	LUTS_3d Folder
Input LUTs	LUTS_input Folder
Still Images	Stills Folder
Monitor Presets	Presets Folder